

LPC-Link2 TP-locations

TP_CLK2 TP_CLK0
TP_P6_0 TP_P1_19

TP_DP1
TP_DM1

TP_RTCX1
TP_RST
TP_RTCX2
TP_RTC_ALARM
TP_WAKEUP
TP_P3_0
TP_ISP

